

QUASAR SERIES Presets & Tunings User Guide

Rev 1.0.2

Publication Date: 16th July 2026

QUASAR CONFIGURATION

OVERVIEW:

This guide explains how to download, extract and load the correct presets and tunings for the Atomik Quasar mid-top loudspeakers. These settings are critical to ensure optimal performance and system protection.

Step 1: Download the Presets & Tunings ZIP File

1. Visit the Quasar product page on the Atomik website.
2. Navigate to the Downloads section.
3. Locate and download the file:
Atomik Quasar – Presets & Tunings.zip

Step 2: Extract the Files

1. Once downloaded, right-click the .zip file and select Extract All (Windows).
2. This will create a folder named:
Atomik Quasar – Presets & Tunings

Step 3: Locate the Preset File

Inside the extracted folder, you'll find multiple preset files organized by configuration type.

- For example:

"LA1-QUASAR P01.p26" for Arrays & Configuration 1.

"LA2-QUASAR P02.p26 for Arrays & Configuration 2.

etc.

Refer to the "Chapter 4" on Pg. 59 of the user manual Rev. 1.0.20 to determine which configuration matches your setup.

Step 4: Load the Preset

1. Connect the XN D26 DSP to your computer via USB.
2. Open the Atomik XN D26 software.
3. Import or load the selected preset file.
4. Verify that the routing, gain structure and limiter settings are correctly applied.

Important Notes

- Always ensure firmware and software are up to date.
- Do not modify EQ or limiter settings unless specified by Atomik support.
- Use only the matched preset for each loudspeaker model to prevent system damage.

For assistance or questions, contact: support@atomikaudio.com